

Bissell®

SPINWAVE CORDLESS

2240 SERIES

- EN BATTERY REMOVAL INSTRUCTIONS
AR تعليمات إزالة البطارية
BG ИНСТРУКЦИИ ЗА ОТСТРАНЯВАНЕ НА БАТЕРИЯТА
BS UPUTSTVA ZA VAĐENJE BATERIJE
CHS 電池拆卸說明
CHT 電池拆卸指南
CZ POKYNY K VYJMUTÍ BATERIE
DE ANWEISUNGEN ZUR AKKUENTNAHME
DK VEJLEDNING FOR FJERNELSE AF BATTERIET
EL ΟΔΗΓΙΕΣ ΑΦΑΙΡΕΣΗΣ ΜΠΑΤΑΡΙΑΣ
ES INSTRUCCIONES PARA RETIRAR LA BATERÍA
ET PATAREI EEMALDAMISE JUHISED
FI AKUN POISTO-OHJEET
FR INSTRUCTIONS CONCERNANT LE RETRAIT DE LA BATTERIE
HE הוראות להוצאת הסוללה
HR UPUTE ZA UKLANJANJE BATERIJE
HU AKKUMULÁTOR ELTÁVOLÍTÁSI ÚTMUTATÓ
IT ISTRUZIONI PER LA RIMOZIONE DELLA BATTERIA
KO 배터리 분리 방법
LT AKUMULIATORIAUS IŠĖMIMO INSTRUKCIJA
LV AKUMULATORA NOŅĒMŠANAS INSTRUKCIJAS
MK УПАТСТВО ЗА ОТСТРАНУВАЊЕ НА БАТЕРИИТЕ
ML ARAHAN MENGALIH KELUAR BATERI
NL INSTRUCTIES VERWIJDEREN ACCU
NO SLIK FJERNER DU BATTERIET
PL INSTRUKCJA DEMONTAŻU AKUMULATORA
PT INSTRUÇÕES DE REMOÇÃO DA BATERIA
RO INSTRUCȚIUNI PENTRU SCOATEREA BATERIEI
RU ИНСТРУКЦИИ ПО ИЗВЛЕЧЕНИЮ БАТАРЕИ
SE INSTRUKTIONER BORTTAGNING AV BATTERIS
SK POKYNY NA VYBRATIE BATÉRIE
SL NAVODILA ZA ODSTRANITEV BATERIJE
SR UPUTSTVO ZA UKLANJANJE BATERIJE
TA பேட்டரியை அகற்றுவதற்கான அறிவுறுத்தல்கள்
TH คำแนะนำการถอดแบตเตอรี่
TR BATARYA ÇIKARMA TALİMATLARI



